

RS SE5 & SM5 INSTALLATION INSTRUCTIONS

RIGHT FLOORBOARD:

1. Unscrew and remove rubber foot peg and rubber brake pads. Set aside for future use.
2. Bolt new brake pedal onto the top of the brake pedal using 1" bolts and nuts. Tighten securely. Make sure brake extends forward. You may want to use LockTight BLUE to keep the nuts secure.
3. Bolt Front Mounting Bracket (Fig. 16 #20) to the underside of the FloorBoard thru the front holes using 1" bolt and nuts. Make sure the horizontal leg of the bracket faces inward toward the bike. Tighten securely.
4. Place FloorBoard on foot peg being sure that the rear FloorBoard Tab is inserted into the decorative SPYDER aluminum foot peg bracket Slot (#12 Fig. 1).
5. Line up rear FloorBoard holes with Foot Peg holes. Bolt down using 1 1/2" bolts. Leave bolts loose for the moment.
6. Place one of the Front Bracket Mounting Clips (Fig 1 #8) behind the SPYDER Aluminum Foot Peg Assembly. Line up the bolt (#8) with the hole (#28) on the Front Mounting Bracket (Fig 16 #20). Bolt in place securely. You may want use LockTight Blue to keep the bolt from vibrating loose. This may take some minor adjusting of the Front Bracket to line up the holes . Tighten the two bolts on the Foot Peg.
7. Push down on Brake to be sure it moves freely in the Brake Slot.

LEFT FLOORBOARD.:

1. Loosen and remove bolt # 326 from the SPYDER shift linkage. Pull the Shift Peg from the "Star Hole" (fig. 11). Mount the new Shift Lever onto the shift Linkage (fig. 12). Replace bolt # 326.
2. Mount floorBoard Bracket to underside of FloorBoard same as Right Floorboard. Securely tighten nuts.
3. Mount FloorBoard unit to your SPYDER the same way as the right side.
4. Recheck all nuts and bolts to see they are securely tightened.
5. Place Brake and Foot Peg Rubber Pads and Shift Bar in a plastic bag and store in a safe place (the trunk of your SPYDER?).

6. With all nuts and bolts tight, you will notice a bit of flex in the "Neck" end of the FloorBoard. This is normal, as there is a slight flex in the SPYDER aluminum foot peg assembly. When stepping on the FloorBoard, step only on the FLAT portion, NOT on the angled neck part. The "Neck" part is only to be used as a foot rest while seated. It is not intended as a heavy load bearing surface.

ENJOY!!!

John

PARTS LIST

2-FLOORBOARDS - 1-RIGHT, 1- LEFT

1-BRAKE PEDAL

2-FRONT MOUNTING BRACKETS - 1 RIGHT, 1-LEFT

1-SHIFT LEVER EXTENSION (SM5 MODLE ONLY)

2- FRONT MOUNTING BRACKET CLIPS

1- 1 1/4" FENDER WASHERS (-FOR MODLE SM5 only)

6-1" BOLTS

5-1 1/2" BOLTS

13-NUTS